



USER GUIDE VIVOO APP




1. Sign Up



B1: Open the Vivoo app and select "Sign Up"




B2: Enter your information, then select "Sign Up"



B3: Open the verification email sent to your inbox.




B4: If the email is in your Spam folder, click "Report not spam" (or "Báo cáo không phải thư rác"). If it's already in your Inbox, skip this step.



B5: Go to your main inbox and select the activation email


1. Sign Up




B6: In the email, click "Activate" or click "Kích hoạt"



B7: When the pop-up notification appears, tap "Allow" or tap "Cho phép"




B8: The app will automatically open and activate your account




B9: Account activated successfully.

2. Sign In




B1: Enter your information, then select "Sign In"




B2: Signed in successfully.

3. Forgot password




B1: Open the app and select "[Forgot password?](#)"



B2: Enter your information, then select "[Send reset link](#)".


4. Change password




B1: On the Home screen, select "Profile", then select "Change password"

B2: Enter your information, then select "Save"


5. Delete account




B1: On the Home screen, select "Profile", then select "Account Information"



B2: Then select "Delete account".




B3: Select "Delete"




B4: After successful deletion, you will return to the Sign In screen

6. Multiple view




B1: On the Home screen, select "Play all"




B2: Multi-camera view


7. Add camera (Wifi)




B1: On the Home screen, select the "+" icon




B2: Select "Add Camera (Wi-Fi)"



B3: Select the camera type, then select "Next"




B4: Select "Next" or select "Skip"




B5: Enter your Wi-Fi information, then select "Next"

7. Add camera (Wifi)




B6: Scan the QR code on the camera




B7: Scan the camera's QR code, then select "Add"



B8: Select "Connect" or Select "Kết nối"




B9: Wait for the app to search and connect to the camera.




B10: Camera added successfully


8. Add camera (LAN)




B1: On the Home screen, select the "+" icon



B2: Select "Add Camera (LAN)"




B3: Select the camera type, then select "Next"




B4: Select "Next"


8. Add camera (LAN)




B5: Select the device, then select "Add"



B6: Select "Add"




B7: Wait for the app to search and connect to the camera




B8: Camera added successfully

9. Options


9.1 Edit label



B1: On the Home screen, select the "...".




B2: Select "Edit label".




B3: Enter the name, then select "Save".


9.2 Device information



B1: On the Home screen, select the "... " icon.




B2: Select "Device information"




B3: View device information.


9.3 Device sharing



B1: On the Home screen, select the "...".




B2: Select "Device sharing"




B3: Enter email, then select "Share"


9.4 Leaving a shared device




B1: On the Home screen, select the "...".



B2: Select "Device sharing".




B3: Select "Leave shared device".




B4: Select "Leave".


9.5 Reclaiming shared devices




B1: On the Home screen, select the "...".



B2: Select "Device sharing".




B3: Click to select the delete icon




B4: Select "Unshare"


9.6 Backup Wi-Fi




B1: On the Home screen, select the "...".



B2: Select "Backup WiFi".




B3: Select wifi




B4: Enter information, then select "Save".


9.7 Change Wi-Fi




B1: On the Home screen, select the "...".



B2: Select "Change WiFi".




B3: Select Wi-Fi.




B4: Enter information, then select "Save".


9.8 Sound warning



B1: On the Home screen, select the "...".




B2: Select "Sound warning".




B3: Sound warning screen


9.9 Alarm schedule



B1: On the Home screen, select the "...".




B2: Select "Alarm schedule".




B3: Alarm schedule screen


9.10 Storage schedule



B1: On the Home screen, select the "...".




B2: Select "Storage schedule"




B3: Storage schedule screen


9.11 Private mode



B1: On the Home screen, select the "... " icon.




B2: Select "Private mode"




B3: Private mode screen


9.12 Camera settings



B1: On the Home screen, select the "...".




B2: Select "Camera settings"




B3: Camera settings screen


9.13 Remove device



B1: On the Home screen, select the "...".





B2: Select "Remove device".




B3: Select "Remove".


10. Smart Event




11. Camera page




11. Camera page




12. Sign Out




B1: On the Home screen, select "Profile", then select "Account information"



B2: Then select "Sign Out"



B3: Select "Sign Out".



B4: After successfully signing out, you will be returned to the Sign In screen